

ENR 3.6 EN-ROUTE HOLDING

The en-route holdings may be used only when indicated as clearance limit or after permission from ATC.

To be supplied later.

THIS PAGE INTENTIONALLY LEFT BLANK